TECHNICAL DRAWINGS


COUNTERTOP — **OVERHANGS**

This describes how to fabricate and install Corian® countertops that overhang up to 18" (457 mm).

Fabricating and Installing Overhang Countertops

Supporting Overhangs

As a general guideline, support is required for overhangs of Corian® containing seams or for 1/2" (13 mm) overhangs extending more than 6" (150 mm) and 3/4" (19 mm) overhangs extending more than 12" (300 mm). Adding thick edges makes the overhang stronger.



Support Types

Refer to the following charts to determine the type(s) of support to use.

Overhang Supports			
FOR OVERHANGS EXTENDING MORE THAN	AND UP TO	INSTALL	
1/2" (13 mm) Corian® Countertop			
0"	6"	No Additional	
(0 mm)	(150 mm)	Support Required	
6"	12"	Plywood Underlayment	
(150 mm)	(300 mm)	or Brackets of Corian®	
12"	18"	Plywood Underlayment	
(300 mm)	(457 mm)	and Brackets of Corian®	
18"	_	Legs or Columns	
(457 m)		5	

Seamed Overhang Supports*	
FOR COUNTERTOPS WIDER THAN	INSTALL
30" (760 mm)	Plywood Underlayment and Reinforcing Strips and/or Edge Buildups of Corian®

C950-K03158-44 1/04



^{*}All seams must be supported. For countertops wider than 30" (760 mm), put the seam in the overhang, not over the cabinet.