

Privacy Plus® Partition Systems

Care and Maintenance

Privacy Plus® partition systems require little or no maintenance however over time scuffs, scratches, cigarette burns and dirt will occur on the Corian® surface. As a renewable surface these damages can easily be removed with basic household and commercial cleaning products.

Approved cleaning agents for the Corian components are:

- Powdered abrasives (like Comet)
- Common household spray cleaners (like Formula 409)
- Ammonia
- Mild or strong detergents
- Oxalic acid solutions
- Diluted hydrochloric acid solutions
- Diluted trisodium phosphate solutions

For stubborn stains and abrasions:

- White Scotch-Brite® pad for gloss finishes
- Green Scotch-Brite® pad for satin/ matte finishes
- 220- 400 grit sandpaper depending on the depth of the abrasion

Avoid strong chemicals such as:

- Strong chlorinated solvents
- Chloroform
- Ketones
- Methylene Chloride (paint removers)
- Very strong acids (concentrated sulfuric and hydrochloric acids)
- Acid drain cleaners

Hinge and Latch Assembly Hardware components require NO maintenance. DO NOT USE:

- CLEANING SOLUTIONS, CHEMICALS, ACID SOLUTIONS, VINEGAR AND ABRASIVES OF ANY KIND ON HARDWARE COMPONENTS.
- DO NOT LUBRICATE THE HINGE AND CAMS AS THEY ARE DESIGNED TO FUNCTION WITHOUT IT. USE OF ANY OF THESE PRODUCTS CAN RESULT IN CORROSION AND/ OR CLOGGING THE CAM AND HINGE KNUCKLES. THE USE OF THESE PRODUCTS ALSO INCREASES THE SERFACE TENSION ON THE CAMS THUS RENDERING THE HINGE UNABLE TO FUNCTION. THIS WILL VOID THE WARRANTY AND REPLACEMENT WILL BE AT THE OWNERS EXPENSE.
- IF A HINGE IS BINDING IT MEANS THAT THE CAMS WERE EXPOSED TO CLEANING SOLUTIONS. DO NOT FORCE THE DOOR! SPRAY THE CAMS AND HINGE PIN AT EACH CAM THOROUGHLY WITH DRY TEFLON SPRAY. DO NOT USE ANY OTHER PRODUCT! THIS SHOULD FREE UP THE MOVEMENT OF THE HINGE. IF SOLUTIONS WERE USED LIBERALLY THE HINGE WILL NEED TO BE DISMANTLED AND CLEANED OF ALL CORROSION AND LUBRICANT BUILDUP. CONTACT US FOR SPECIFIC CLEANING INSTRUCTIONS.
- Dust and dirt buildup should be removed with a dry clean cloth only.
- For additional information and guidance contact us at: 847.760.0543